

**INSTRUCTIONS 1005-A00 e**

Section	1005
Effective	September 2018
Replaces	December 2012

Translation of the
original instructions

Pump AB H

INSTALLATION

OPERATION

MAINTENANCE

WARRANTY :


TM Series pumps are covered 24 months by warranty within the limits mentioned in our General Sales Conditions. In case of a use other than that mentioned in the Instructions manual, and without preliminary agreement of MOUVEUX, warranty will be canceled.



Z.I. La Plaine des Isles - F 89000 AUXERRE - FRANCE
Tel. : +33 (0)3.86.49.86.30 - Fax : +33 (0)3.86.49.87.17
contact@mouvex.com - www.mouvex.com

Your distributor :

INSTALLATION



- Standard parts (802 à 810) are replaced in compensated bypass by special parts (822 to 833).

Rotation

MOUVEX pump is reversible. Suction and discharge ends are bound to rotation as indicated on plate fixed to pump.

Bypass orientation

Functioning

Acting as a relief valve, the MOUVEX bypass protects pump and auxiliary equipment from damage due to excessive pressures that may be built up when the pump runs against some obstruction in the discharge piping.

When discharge pressure reaches the pressure limit for which the bypass is set, the valve opens and thus allows the liquid to be circulated from the suction side back to the suction side.

Orientation

The bypass protects the pump in one direction of rotation only. Therefore make sure it is rightly installed by checking that bypass cap is on the suction side and reverse bypass if necessary.

Reversing

Remove adaptor 808 and parts coming with it (805-806-807-808-809-810). Remove valve 803, spring 804 and fit those parts on the opposite side.

Fit plug 812, and gasket 807 in the place of nut 808 (in special low-pressure bypass, seat 822 must be reversed).

Motor protection

As the bypass protects the pump only, electric motors should be equipped with their own protection device.

OPERATION

Pressure setting

To set bypass, remove cap.

To increase pressure setting, turn adjusting nut 806 (or 826) clockwise.

To reduce pressure setting, turn the nut counterclockwise.

Replace cap 833.

Delivery adjustment

When the pump does not deliver the proper flow rate, the trouble may come from bypass spring not being adjusted at the correct pressure setting.


After making sure that the rotation speed is correct, tighten adjusting screw 806.

Should the spring be completely tightened or the motor operation disturbed, without getting the delivery wanted, it would mean that the unit should operate at a higher pressure than the pressure for which it has been designed. Please report to our Technical Department.

Standard bypass use

Standard bypass should not be operated too frequently—even less permanently—since it would result in useless power consumption and material fatigue detrimental to equipment life.

DISASSEMBLY / REASSEMBLY



Disassembly

To remove head and piston

Remove head bolts 410.

Remove end-plate 401 by prying it loose.

Using a screwdriver as a lever, back piston 301 away from pump and remove it.

To remove shaft seal and shaft

Refer to § SHAFT SEAL.

Reassembly

Before assembling pump in the reverse order, check the following points :


- piston backsprings 310 (23,5 mm mini).
- spring 504 of piston bearing has not weakened.

Replace shaft and shaft seal (see § SHAFT SEAL).

Before refitting end-plate, do not forget to refit gasket 403 after making sure it is in good condition.

SHAFT SEAL

BLOCDIR SHAFT SEAL AB H



Operation

Shaft 501 rotates through driver 616, cup 612, spring 615, thrust spring 614 and seal 613.

Counterpart 604 is held solid with the pump body by seal 605.

Sealing is ensured :

- 1) On the shaft, by seal 613 that turns with the shaft.
- 2) By the contact surface between rotating cup 612 and immobile counterpart 604.
- 3) In the bore of the pump body, by seal 605 held tightly between counterpart 604 and the pump body.

Sealing therefore depends on the condition of the contact surfaces and of the sealing provided by seal 605 and 613.

Disassembly

After opening the pump :

- Remove the 3 screws 706 and cover 705, draw out cage 701 with the shaft, the bearing and all the parts forming the shaft seal.
- Remove retainer ring 704.
- Drive the shaft out of the bearing by tapping slightly on the shaft on the drive side and withdraw assembly 701, 703 and also 606.
- Remove 604 and 605 and then assembly 612-613-614-615-616.

Reassembly

Check condition of seal 605 and 613.

Check that the contact surfaces of counterpart 604 and of cup 612 are flat and polished.

Reassemble all the parts on the shaft in reverse order of disassembly and fit retainer ring 704. Check that stud 727 of counterpart 604 enters the leak port of bearing cage 701.

Replace the shaft, bearing and shaft seal on the pump, taking care to place the leak drain port downwards and then fit cover 705 and the 3 screws 706.

STORAGE

If necessary, refer to § DISASSEMBLY / REASSEMBLY for pump disassembly.

Short duration (≤ 1 month)

 WARNING	
	IF PUMPING HAZARDOUS OR TOXIC FLUIDS, THE SYSTEM MUST BE FLUSHED PRIOR TO PERFORMING ANY SERVICE OPERATION.
Toxic or hazardous fluids can cause serious injury.	

MOUVEX pumps and motor-driven pumps are well lubricated when delivered to protect the internal parts during brief storage in a building where :

- the temperature remains between 10°C and 50°C.
- the relative humidity does not exceed 60%.
- exposure to vibration is limited.
- pump is stored in an area sheltered from bad weather and sun.

Long duration (> 1 month)

The recommendations from the manufacturer should be followed if the pump is stored with its gear motor.

Pump ports should be filled with a non-corrosive liquid that is compatible with the pump components in order to prevent corrosion.

Unpainted external surfaces of the pump (e.g. shafts, couplings, etc.) should be covered in some form of anti-corrosion protection.

The bearing should be well greased. If the pump is to be stored for more than the life of the grease, this one should be replaced in time to prevent an excessive degradation of its qualities.

The best storage conditions are inside a building that meets the conditions set out above.

If inside storage is not possible, the materials should be covered to prevent direct exposure to sun and bad weather. This protection should also prevent condensation.

The pump should be turned a few revolutions manually every two months.

Restarting

Follow the standard start-up procedure for the pump/motor-driven pump, as well as the instructions below.

Turn the pump by hand to make sure the parts move freely.

Replace the grease used to lubricate the bearing.

If the pump has a safety bypass, remove it and inspect the parts and make sure they move freely (see § BYPASS for removal instructions).

SCRAPPING

The pump must be scrapped in compliance with the regulations in force.

During this operation, particular care must be paid to the drainage stages of the pump.



DECLARATION UE DE CONFORMITE CE

EU CERTIFICATE OF CONFORMITY – EU KONFORMITÄTSERKLÄRUNG

MOUVEX sas, ZI La Plaine des Isles – 2 Rue des Caillottes – 89000 Auxerre France, déclare que l'équipement suivant / declares the following equipment / erklärt, dass folgende Ausrüstung:

Modèle :

Designation / Bezeichnung

Pour la Sté MOUVEX sas, fait à Auxerre le : _____

For Mouvex sas company – Date :

Für die Fa Mouvex sas - Datum :

N° de série : _____

Serial N° / Serien Nr

(A) Répondant aux spécifications indiquées dans l'ARC N° : _____ (B)

Entsprechend den Spezifikationen aus AB-Nr. :

Configuration :

Konfiguration

(A) According to the specifications recorded in the acknowledgment of order N°:

- Pompe / Compresseur arbre nu (Pump / Kompressor, *bare-shaft*)
- Pompe à palettes (Vane Pump / *kompressoraggregat*)
- Pompe à lobes (Lobes Pump / Drehkolbenpumpe)
- Pompe à palettes (Vane Pump / *Flügelzellenpumpe*)
- Autre pompe (Other Pump / *Ardere Pumpe*)

Responsable Qualité Clients / Qualitätsbeauftragter

Customer Quality Manager / Qualitätsbeauftragter

Is in conformity with the provisions of the following Directive:



- « MACHINES » Directive 2006/42/EEC as transposed by the national legislation, concerning safety equipments and arrangements relative to mechanical and electric risks applicable to rotating machines.
- NF EN ISO 13857:2008
- NF EN 1672-2:2009
- NF EN 12162:2009
- NF EN 809:2009
- NF EN 1672-2:2009
- NF EN 12162:2009

- « ATEX » Directive 2014/34/EU (26 Feb. 2014) as transposed by the national legislation, concerning equipment intended to be used in explosive atmospheres. Conformity obtained by application of the standards:
- NF EN 1127-1:1997
- NF EN 13463-1:2009
- NF EN 13463-5:2009
- ATEX Certification delivered by INERIS*, Notified Body, and with the following marking: (C)

Die ATEX-Zertifizierung wurde von der benannten Stelle (NERIS*) erteilt, und mit folgender Kennzeichnung: (C)



(X = voir notice / see IOM / siehe Handbuch)

L'équipement désigné ci-dessus doit impérativement respecter les conditions d'utilisation ATEX décrites dans nos notices d'instruction. Il doit être employé conformément à l'utilisation qui en a été prévue de par sa conception et sa fabrication, et conformément aux normes en vigueur. Nous, soussignés, déclarons que l'équipement concerné est conforme aux Directives listées ci-dessus et aux normes applicables s'y rapportant.

The equipment indicated above must imperatively comply with the ATEX conditions of use described in our instruction book. It must be used according to the foreseen use by its design and its manufacturing, and according to the current standards.

We, undersigned, declare that the concerned equipment is in conformity with the Directives listed above and in the applicable standards in force.

Oben stehend bezeichnete Ausrüstung muss unbedingt den in unseren Betriebsanleitungen beschriebenen Anwendungsbedingungen entsprechen. Sie ist entsprechend dem durch Konstruktion und Fabrikation vorgesehenen Verwendungszweck und entsprechend den geltenden Normen einzusetzen.

Die Unterzeichner erklären, dass die bezeichnete Ausrüstung den oben aufgeführten Richtlinien und den diesbezüglich geltenden Normen entspricht.