

**INSTRUCTIONS 1005-C00 e**

Section	1005
Effective	September 2018
Replaces	December 2012

Translation of the  
original instructions

# *Pump AF TM H*

***INSTALLATION******OPERATION******MAINTENANCE*****WARRANTY :**


TM Series pumps are covered 24 months by warranty within the limits mentioned in our General Sales Conditions. In case of a use other than that mentioned in the Instructions manual, and without preliminary agreement of MOUVEUX, warranty will be canceled.



Z.I. La Plaine des Isles - F 89000 AUXERRE - FRANCE  
Tel. : +33 (0)3.86.49.86.30 - Fax : +33 (0)3.86.49.87.17  
[contact@mouvex.com](mailto:contact@mouvex.com) - [www.mouvex.com](http://www.mouvex.com)

Your distributor :

# INSTALLATION



D : Bypass  
E : Bypass cap  
F : Fixing stud and nut  
G : Bearing nipple

## Rotation

MOUVEX pump is reversible. Suction and discharge ends are bound to rotation as indicated on plate fixed to pump.

## Bypass orientation

### Operation

Acting as a relief valve, the bypass protects pump and auxiliary equipment from damage due to excessive pressures that may be built up when the pump runs against some obstruction in the discharge piping.

When discharge pressure reaches the pressure limit for which the bypass is set, valve **803** opens and thus allows the liquid to be circulated from the discharge side back to the suction side.

### Orientation

The single bypass protects the pump in one direction of rotation only.

Therefore make sure it is rightly installed by checking that bypass cap is on the suction side and reverse bypass if necessary.

### Reversing

To reverse bypass, remove nuts **814** and rotate bypass body by 180°.


Check gaskets **877**.

Tighten nuts **814** taking care to keep bypass on end.

## Motor protection

As the bypass protects the pump only, electric motors should be equipped with their own protection device.

# UTILISATION



## Temperature of pumped product

AF TM H pumps are suitable for pumping domestic fuel and heavy fuel heated up to 0° C and 180° C with the following recommendations :

- before transferring heavy fuel, preheat the whole installation
- rinsing the installation with domestic fuel immediately after each operation with heavy fuel.

For others conditions of use, report to our Technical Department.

## Pressure setting

To set bypass, remove cap 833. To increase pressure setting, turn adjusting nut 834 clockwise. To reduce pressure setting, turn the nut counterclockwise.

When the setting is finished, dont forget to replace cap 833.

With the bypass spring, it is possible to set the pressure between 1,7 and 6,5 bar (valve closed).

## Delivery adjustement

When the pump does not deliver the proper flow rate, the trouble may come from bypass spring not being adjusted at the correct pressure setting.


After making sure that the rotation speed is correct, tighten adjusting nut 834.

Should the spring be completely tightened or the motor operation disturbed, without getting the delivery wanted, it would mean that the unit should operate at a higher pressure than the pressure for which it has been designed. Please report to our Technical Department.

## Standard bypass use

Standard bypass use should not be operated too frequently (even less permanently) since it would result in useless power consumption and material fatigue detrimental to equipment.

# DISASSEMBLY / REASSEMBLY



## **Disassembly**

### **Opening the pump :**

- Remove end-plate bolts **409**.
- Remove end-plate **401** by prying it loose. Using a screwdriver as a lever, back piston **301** and shaft **501** away from pump.

### **To remove piston :**

- Free the piston **301** by sliding it along the shaft **501**.

### **To remove shaft seal, bearing and shaft :**

- Refer to § SHAFT SEAL.

## **Reassembly**

Reassembly is undertaken in the reverse order of dismantling. Before assembling, check that spring **504** of piston bearing **503** and piston backsprings **310** has not weakened.

### **To reassemble shaft seal, bearing and shaft :**


- Refer to § SHAFT SEAL.

### **To reassemble piston and to close the pump :**

- After remounting in place the seal end-plate **403**, engage the piston **301** on the shaft **501**.
- Insert the piston **301** in the cylinder **201**, by making bend the spring **504** of piston bearing **503** and push tight to the end.
- The end-plate **401** has to come effortlessly to apply on the cylinder **201**.
- Screw the end-plate bolts **409**.

**Nota -** When you reassemble the pump, make sure seals are in good condition.

# SHAFT SEAL



## Operation

MONOSIR block 601 is held in shaft by its rubber face. Stationary seal 604 is held in pump body by ring 605. Tight sealing depends on :

- ring 605 and rubber face of 601.
- sealing faces being perfectly flat and mirror smooth, of stationary seal 604 and 601.

## Disassembly

After opened the pump :

- remove screws 706 and washers 721, cap 705, outer seal 707 and drive out retainer 701 with shaft, bearing and all parts constituting the shaft seal.
- remove snap ring 704, drive out shaft from bearing by tapping on shaft end and remove the set 701-731-733-703.
- remove the set 604-605, then all MONOSIR block 601.

MONOSIR block 601 must not be dissociated.

## Reassembly

- Check rings 707, 605 and rubber faces of block 601.
- Check that sealing faces of 604 and block 601 are flat and mirror smooth.
- Replace all parts on shaft in the reverse order and install snap ring 704.
- Replace on the pump shaft, ball bearing and shaft seal making sure one of the drain vents is turned downwards.
- Then, install seal 707 taking care not to damage seal 707 on key-groove, bearing cap 705 (bearing grease nipple turned upwards), screws 706 and washers 721.

# STORAGE

If necessary, refer to § DISASSEMBLY / REASSEMBLY for pump disassembly.

## Short duration ( $\leq 1$ month)

 <b>WARNING</b>	
	IF PUMPING HAZARDOUS OR TOXIC FLUIDS, THE SYSTEM MUST BE FLUSHED PRIOR TO PERFORMING ANY SERVICE OPERATION.
Toxic or hazardous fluids can cause serious injury.	

MOUVEX pumps and motor-driven pumps are well lubricated when delivered to protect the internal parts during brief storage in a building where :

- the temperature remains between 10°C and 50°C.
- the relative humidity does not exceed 60%.
- exposure to vibration is limited.
- pump is stored in an area sheltered from bad weather and sun.

## Long duration ( $> 1$ month)

The recommendations from the manufacturer should be followed if the pump is stored with its gear motor.

Pump ports should be filled with a non-corrosive liquid that is compatible with the pump components in order to prevent corrosion.

Unpainted external surfaces of the pump (e.g. shafts, couplings, etc.) should be covered in some form of anti-corrosion protection.

The bearing should be well greased. If the pump is to be stored for more than the life of the grease, this one should be replaced in time to prevent an excessive degradation of its qualities.

The best storage conditions are inside a building that meets the conditions set out above.

If inside storage is not possible, the materials should be covered to prevent direct exposure to sun and bad weather. This protection should also prevent condensation.

The pump should be turned a few revolutions manually every two months.

## Restarting

Follow the standard start-up procedure for the pump/motor-driven pump, as well as the instructions below.

Turn the pump by hand to make sure the parts move freely.

Replace the grease used to lubricate the bearing.

If the pump has a safety bypass, remove it and inspect the parts and make sure they move freely (see § BYPASS for removal instructions).

# SCRAPPING

The pump must be scrapped in compliance with the regulations in force.

During this operation, particular care must be paid to the drainage stages of the pump.



# DECLARATION UE DE CONFORMITE CE

## EU CERTIFICATE OF CONFORMITY – EU KONFORMITÄTSERKLÄRUNG

**MOUVEX sas, ZI La Plaine des Isles – 2 Rue des Caillottes – 89000 Auxerre France, déclare que l'équipement suivant / declares the following equipment / erklärt, dass folgende Ausrüstung:**

**Modèle :** \_\_\_\_\_ **N° de série :** \_\_\_\_\_ (A) Répondant aux spécifications indiquées dans l'ARC N° : \_\_\_\_\_ (B)  
Designation / Bezeichnung

**Pour la Sté MOUVEX sas, fait à Auxerre le :** \_\_\_\_\_

**For Mouvex sas company – Date :** \_\_\_\_\_

**Für die Fa Mouvex sas - Datum :** \_\_\_\_\_

**Responsable Qualité Clients / Qualitätsbeauftragter**

**Customer Quality Manager / Qualitätsbeauftragter**

**Est conforme aux dispositions suivantes :**

- Directive « MACHINES » 2006/42/CE et aux législations nationales la transposant, portant sur les dispositifs de sécurité liés aux risques mécaniques et électriques applicables aux machines tournantes.  
NF EN 809:2009 NF EN 1672-2:2009 NF EN ISO 13857:2008  
NF EN 12162:2009 NF EN 12162:2009 NF EN 1672-2:2009 NF EN 13857:2008
- Directive « ATEX » 2014/34/EU du 26 février 2014 et aux législations nationales la transposant, portant sur les appareils destinés à être utilisés en atmosphères explosives. Conformité obtenue par application des normes :  
NF EN 1127-1:1997 NF EN 13463-1:2009 NF EN 13463-5:2009 Certification ATEX délivrée par INERIS\*, Organisme Certificateur, et portant le marquage suivant : (C)



L'équipement désigné ci-dessus doit impérativement respecter les conditions d'utilisation ATEX décrites dans nos notices d'instruction. Il doit être employé conformément à l'utilisation qui en a été prevue de par sa conception et sa fabrication, et conformément aux normes en vigueur. Nous, soussignés, déclarons que l'équipement concerné est conforme aux Directives listées ci-dessus et aux normes applicables s'y rapportant.

The equipment indicated above must imperatively comply with the ATEX conditions of use described in our instruction book. It must be used according to the foreseen use by its design and its manufacturing, and according to the current standards.

We, undersigned, declare that the concerned equipment is in conformity with the Directives listed above and in the applicable standards in force.

(X = voir notice / see IOM / siehe Handbuch)

Oben stehend bezeichnete Ausrüstung muss unbedingt den in unseren Betriebsanleitungen beschriebenen Anwendungsbedingungen entsprechen. Sie ist entsprechend dem durch Konstruktion und Fabrikation vorgesehenen Verwendungszweck und entsprechend den geltenden Normen einzusetzen.  
Die Unterzeichner erklären, dass die bezeichnete Ausrüstung den oben aufgeführten Richtlinien und den diesbezüglich geltenden Normen entspricht.

<b>N° de série :</b> _____	<b>Serial N° / Serien Nr</b>	<b>According to the specifications recorded in the acknowledgment of order N°:</b> _____
<b>Configuration :</b> _____		
<b>Konfiguration</b>		
<input type="checkbox"/> Pompe / Compresseur arbre nu (Pump / Compressor « bare-shaft ») <input type="checkbox"/> Pompe / Compresseur arbres (Pump / Kompressor « freies Wellende */		
<input type="checkbox"/> Pompe à mvt excentré (Eccentric Disc Pump / Kingkollbenpumpe) <input type="checkbox"/> Pompe péristaltique (Peristaltic Pump / Schlauchpumpe) <input type="checkbox"/> Pompe centrifuge (Centrifugal Pump / Kreiselpumpe) <input type="checkbox"/> Compresseur à Vis (Screws compressor / Schraubenverdichter) <input type="checkbox"/> Compresseur à palettes (Vane compressor / Flügelzellenverdichter) <input type="checkbox"/> Refroidisseur Hydraulique (Hydraulic oil cooler / Hydraulikkühler)		
<b>Type / Gerätart :</b> <input type="checkbox"/> Pompe à mvt excentré (Eccentric Disc Pump / Kingkollbenpumpe) <input type="checkbox"/> Pompe péristaltique (Peristaltic Pump / Schlauchpumpe) <input type="checkbox"/> Pompe centrifuge (Centrifugal Pump / Kreiselpumpe) <input type="checkbox"/> Compresseur à Vis (Screws compressor / Schraubenverdichter) <input type="checkbox"/> Compresseur à palettes (Vane compressor / Flügelzellenverdichter) <input type="checkbox"/> Refroidisseur Hydraulique (Hydraulic oil cooler / Hydraulikkühler)		
<b>den Bestimmungen der nachstehenden Richtlinien entspricht:</b> <input type="checkbox"/> „Maschinen-Richtlinie“ 2006/42/EEC wie umgesetzt im nationalen Recht hinsichtlich der Ausrüstungssicherheit und Sicherheitsvorkehrungen auf mechanische und elektrische Risiken, die für rotierende Maschinen gelten. NF EN 809:2009 NF EN 1672-2:2009 NF EN ISO 13857:2008 NF EN 12162:2009 NF EN 12162:2009 NF EN 1672-2:2009 NF EN 13857:2008		
<input type="checkbox"/> „ATEX“ Richtlinie 2014/34/EU (26. Feb. 2014), wie umgesetzt im nationalen Recht in Bezug auf Ausrüstungen für den Einsatz in explosionsgefährdeten Atmosphären. Die Konformität hat Geltung durch Anwendung folgender Normen: NF EN 1127-1:1997 NF EN 13463-1:2009 NF EN 13463-5:2009 ATEX Certification delivered by INERIS*, Notified Body, and with the following marking: (C) Die ATEX-Zertifizierung wurde von der benannten Stelle (NERIS*) erteilt, und mit folgender Kennzeichnung: (C)		

<b>den Bestimmungen der nachstehenden Richtlinien entspricht:</b> <input type="checkbox"/> „Maschinen-Richtlinie“ 2006/42/EEC wie umgesetzt im nationalen Recht hinsichtlich der Ausrüstungssicherheit und Sicherheitsvorkehrungen auf mechanische und elektrische Risiken, die für rotierende Maschinen gelten. NF EN 809:2009 NF EN 1672-2:2009 NF EN ISO 13857:2008
<b>Is in conformity with the provisions of the following Directive:</b> <input type="checkbox"/> « MACHINES » Directive 2006/42/EC as transposed by the national legislation, concerning safety equipments and arrangements relative to mechanical and electric risks applicable to rotary machines. NF EN 809:2009 NF EN 1672-2:2009 NF EN ISO 13857:2008 NF EN 12162:2009 NF EN 12162:2009 NF EN 1672-2:2009 NF EN 13857:2008
<b>Is in conformity with the provisions of the following Directive:</b> <input type="checkbox"/> « ATEX » Directive 2014/34/EU (26. Feb. 2014) as transposed by the national legislation, concerning equipment intended to be used in explosive atmospheres. Conformity obtained by application of the standards: NF EN 1127-1:1997 NF EN 13463-1:2009 NF EN 13463-5:2009 ATEX Certification delivered by INERIS*, Notified Body, and with the following marking: (C)