


PARTS LIST
PUMP
AF TM H

Keep this parts lists with Installation, Operation and Maintenance Instructions.


To order the required spare parts, indicate the desired Reference(s).

◆ Sets of parts or parts available to order.


AF TM H



Mechanical seal



Bypass



AF TM H

* 1, 2, 4... : Quantity in equipment - (1), (2), (4)... : Quantity in kit

Item	Available	Description	Qty*	Ref.	Maintenance kit	Wear part
98	◆	FULL SET OF SCREWS	1	301332.00		
202		STUD	(8)			
206		NUT	(8)			
409		SCREW	(6)			
409A		NUT	(6)			
417		SCREW	(4)			
420		WASHER	(4)			
706		SCREW	(4)			
721		WASHER	(4)			
99	◆	SET OF PUMP SEALS	1	301339.00	■	
104		SEAL	(1)			
403	◆	SEAL	1	200834		
406		SEAL	(2)			
416		SEAL	(1)			
100	◆	MAIN BODY, COMPLETE	1	300445.00		
101		MAIN BODY	(1)			
817	◆	SET OF BYPASS FIXING STUDS	1	300447.00		
813		NUT	(2)			
814		STUD	(2)			
815		WASHER	(2)			
200	◆	CYLINDER, COMPLETE	1	300448.01	■	●
201		CYLINDER	(1)			
202		STUD	(8)			
206		NUT	(8)			
300	◆	COMPLETE PISTON	1	301337.00	■	●
301O		PISTON + BLOCK PIN	(1)			
303	◆	PISTON BUSHING	1	201366	■	●
398O	◆	SLIDE BLOCK, COMPLETE	1	305218.00		
305		ABUTMENT	(1)			
307	◆	SLIDE BLOCK + BUSHING	1	300459.00		
306		BUSHING	(1)			
312		SLIDE BLOCK	(1)			
308		WASHER	(1)			
309		PISTON NUT	(1)			
399	◆	GUIDE BLOCK, COMPLETE	1	300462.00		
310		SPRING	(3)			
311		BACK PISTON SUPPORT	(3)			●
400	◆	COMPLETE FRONT COVER	1	300484.00		
401		FRONT COVER	(1)			
402	◆	FRONT BUSHING SET	1	300486.00		
404		GUIDE	(2)			●
405		STUD	(2)			
406		SEAL	(2)			
407		WASHER	(2)			
408		NUT	(2)			
411	◆	FRONT COVER DRAIN PLUG + SEAL	1	300036.00		
412		SEAL	(1)			
434		PLUG	(1)			
403	◆	SEAL	1	200834		
413	◆	FRONT COVER BEARING COMPLETE	1	301327.00		
414		FRONT COVER BEARING	(1)			
415	◆	BEARING BUSHING	1	201390	■	●
416		SEAL	(1)			
417		SCREW	(4)			
420		WASHER	(4)			

AF TM H

* 1, 2, 4... : Quantity in equipment - (1), (2), (4)... : Quantity in kit

Item	Available	Description	Qty*	Ref.	Maintenance kit	Wear part
500	◆	SHAFT BLOCDIR COMPLETE	1	301338.00	■	
501	◆	SHAFT	1	204235		
503	◆	PISTON BEARING	1	203509		●
504		SPRING	(1)			
508	◆	KEY	1	204523		
600	◆	MECHANICAL SEAL BLOCDIR LR VT	1	300387.00	■	
610		STATIONARY SEAL FACE COMPLETE	(1)			
604		STATIONARY SEAL FACE	(1)			
605		SEAL	(1)			
697		ROTATING PART	(1)			●
612		SEAL HOUSING	(1)			●
613		SEAL	(1)			
614		SPRING GUIDE	(1)			
615		SPRING	(1)			
616		CAGE	(1)			
699	◆	SET OF MECHANICAL SEAL SEALS	1	300513.00		
605		SEAL	(1)			
613		SEAL	(1)			
704		RING	(1)			
700	◆	BALL BEARINGS COMPLETE	1	311565.00		
627	◆	PIN	1	200139		
701		BEARING CAGE	(1)			
703	◆	BALL BEARING	1	212314		●
705		BEARING COVER	(1)			
706		SCREW	(4)			
708		GREASE NIPPLE	(1)			
721		WASHER	(4)			
797	◆	BALL BEARING WASHERS AND GASKET SET	1	300505.00		
704		RING	(1)			
707		LIP SEAL	(1)			
717		SEAL	(1)			
731		WASHER	(2)			
733		METALLIC SEAL	(1)			
800	◆	BYPASS COMPLETE	1	302507.00		
804	◆	SPRING	1	201179		
860	◆	BYPASS BODY COMPLETE	1	300535.00		
801		BYPASS BODY	(1)			
812		PLUG	(1)			
848		SEAL	(1)			
869	◆	BYPASS CAP AND GASKET	1	300541.00		
832		SEAL	(1)			
833		BYPASS CAP	(1)			
878	◆	CENTERING SET	1	300539.00		
876		CENTERING PIECE	(2)			
877		CENTERING GASKET	(2)			
898	◆	SET ADJUSTING SCREW	1	306922.00		
803		VALVE + STEM	(1)			
807		SEAL	(1)			
825		SPRING GUIDE	(1)			
826		ADJUSTING SCREW	(1)			
828		NUT	(1)			
829		SPRING	(1)			
831		PIN	(1)			
834		NUT	(1)			
837		SEAL	(1)			

AF TM H

* 1, 2, 4... : Quantity in equipment - (1), (2), (4)... : Quantity in kit

Item	Available	Description	Qty*	Ref.	Maintenance kit	Wear part
899	◆	SET OF BYPASS SEALS	1	303248.00	■	
807		SEAL	(1)			
829		SPRING	(1)			
831		PIN	(1)			
832		SEAL	(1)			
837		SEAL	(1)			
846		SEAL	(1)			
848		SEAL	(1)			
877		CENTERING GASKET	(2)			